

Torian SuperSuede “Alcantara Style” Wrapping Film – Dry Apply Application Guide

Torian SuperSuede is a premium self-adhesive interior wrap film with a luxurious, tactile Alcantara-style texture. Specifically designed for interior customisation, this film combines aesthetic elegance with conformability and ease of application for a wide range of surfaces including dashboards, door panels, trims, consoles, and furniture.

To achieve optimal results, please follow the steps below:



✓ Key Features

- Ultra-Soft Suede Texture – Offers an authentic, velvety touch and deep matt appearance for a refined, premium finish.
- High-Performance Adhesive System – Features advanced repositionable adhesive technology for smooth, bubble-free installation on complex surfaces.
- Flexible and Conformable – Adapts easily to curves, contours, and interior detailing, ensuring a seamless, professional result.
- Durable & Hard-Wearing – Resistant to abrasion, UV, and daily wear, maintaining its rich texture and colour integrity over time.
- Non-Reflective Matt Finish – Reduces glare, making it ideal for dashboards, trims, door panels, and headliners.
- Lightweight Construction – Adds a luxurious finish without significant additional weight—perfect for motorsport interiors.
- Customisable & Easy to Maintain – Available in a selection of rich colours; easy to clean with a simple wipe-down.

✓ 1. Preparation

Before application, ensure the recommended tools and conditions are in place:

Surface Preparation:

1. Clean the surface thoroughly with IPA to remove all dust, grease, silicone, and residues.
2. Dry the surface with a lint-free cloth. Suede must not be applied to damp or dirty surfaces.
3. Ensure the surface is smooth and non-porous. For textured plastics or porous panels, primer or a surface sealer may be required.

✓ 2. Tools Required

- Felt or Felt-edge squeegee (avoid hard plastic or metal squeegees)
- Precision knife with new blades
- Heat gun (optional, for light manipulation – use very low heat)
- Isopropyl alcohol (IPA) 70% or higher
- Lint-free cloths
- Micro-squeegees or tucking tools
- Gloves (optional but recommended to avoid surface contamination)
- Scissors
- Primer (optional, depending on target substrate)
- Spray Glue (optional, depending on target substrate)
- Masking tape

✓ 3. Application Steps.

Temperature Range:

- Ideal application temperature: +15° C to +25° C
- Minimum surface temperature: +15° C

1. Positioning:

- Cut the film to size, allowing an overhang for wrapping edges.
- Gently tack the film in position using light finger pressure.

2. Adhesive Activation:

- The adhesive is pressure-activated and repositionable during initial placement.
- Do not over-stretch the film, unlike standard cast wraps, the Suede texture may distort under tension.

3. Application:

- Use a felt-edge squeegee to press the film into place with firm, even strokes.
- Work from the centre outwards to avoid air entrapment.
- Avoid excessive heat – use only very low heat to slightly soften the film around curves or edges if needed. Excessive heat can flatten the texture permanently.

4. Edges & Finishing:

- Gently press film into recesses or curves, trimming cleanly with a sharp blade.
- Do not overstretch around tight corners – use relief cuts if necessary.
- Post-heating is not required for this film, but warming slightly to 20–30° C on edges can improve edge grip.

✓ 5. Aftercare & Maintenance

- Clean with a damp microfiber cloth only.
- Do not scrub, use solvents, or pressure wash.
- This film is intended for interior use only and should not be exposed to prolonged UV or any outdoor conditions.

✓ 6. Key Installer Tips

- Always apply in manageable sections; avoid overstretching.
- Always perform a small test area on difficult or unknown substrates before full application.
- The Suede film is not suitable for exterior applications or high-wear zones (e.g., gear-sticks, steering wheels).
- Torian.Group cannot be held responsible for improper use or surface compatibility issues.

✓ 7. Summary

- Enhances Visual and Tactile Quality – Transforms any cockpit or interior space with a true luxury aesthetic.
- Improves Driver Experience – The soft-touch, anti-glare finish provides comfort and focus during high-performance driving.
- Professional-Grade Application – Designed for installers who demand precision, conformity, and long-term reliability.
- Adds Value to Builds – Elevates the overall presentation of vehicles, displays, or interiors, increasing perceived value and craftsmanship.
- When installed following this guide, you can expect long-lasting performance and alcantara style finish every time.

✓ **For installation training please contact sales@torian.group.**

Torian® Warranty

Due to the great variety of substrates and the growing number of new applications, the installer must check the suitability of the product for each application. In case of doubt, please request an expert evaluation of the compatibility of the film and the surface in question. All of the published information is based on measurements regularly performed in the laboratory. The published information does not however constitute a binding guarantee. The seller cannot be held liable for indirectly related damages and assumes no liability for claims that are higher than the replacement value of the purchased product. All specifications are subject to potential changes without prior notice.